



HEAT PUMP FOR SWIMMING POOL
Installation and Instruction Manual



Table of contents

Table of contents	2
1. Preface	3
2. Specifications	4
2.1 Performance data	4
3. Installation and connections	5
3.1 Remarks	5
3.2 Heat pump location	5
3.3 How close to the pool?	5
3.4 Typical configuration	6
3.5 Water connections	6
3.6 Electrical connection	7
3.7 Initial startup of the unit	7
3.8 Condensation	8
4. Guidelines	9
4.1 Water chemistry	9
4.2 Winterizing	9
4.3 Spring startup	9
4.4 Control	10
5. Usage and operation	11
5.1 The display	11
5.2 Setting of the wanted temperature	11
5.3 The flow bar	11
6. Maintenance and inspection	12
6.1 Maintenance	12
6.2 Trouble shooting guide	12
6.3 Error messages	13
7. Warranty	14

1. Preface

In order to provide our customers with quality, reliability and versatility, this product has been made to strict producing standards. This manual includes all necessary information about installation, debugging, discharging and maintenance. Please read this manual carefully before you open or maintain the unit. Failure to comply with these recommendations will void warranty.

The manufacturer of this product will not be held responsible if someone is injured or the unit is damaged, as a result of improper installation, debugging or unnecessary maintenance.

The Swimming Pool Heat Pump Unit heats the swimming pool water and keeps the temperature constant.

Our ECO+ heat pumps have the following characteristics:

1. Durable

The heating exchanger is made of PVC & Titanium tube, which can withstand prolonged exposure to swimming pool water.

2. Flexible installation

All our heat pumps are fully tested and ready for use when they leave our factory. Simply connect swimming pool water to the heat pump and insert the electrical plug into a wall socket.

3. Quiet operation

The unit comprises an efficient rotary compressor and a low-noise fan motor, which guarantees its quiet operation.

4. Easy operation

The electronic control panel permits easy setting of the desired temperature. All relevant information regarding the heat pump's operation can be read on this display.

2. Specifications





2.1 Performance data

	Model	ECO+4	ECO+6	ECO+9	ECO+14
Heating capacity	kW	3,9	5,7	8,6	14,1
Power input	kW	0,8	1,05	1,55	2,65
Maximum pool volume *	m ³	12	20	30	45
Running current	A	3,5	4,6	6,5	11,7
COP **		4,9	5,2	5,4	5,3
Power supply	V/Ph/HZ	220-240/1/50	220-240/1/50	220-240/1/50	220-240/1/50
Controller		Digital with built-in diagnostics			
Heat exchanger		Titanium			
Compressor quantity		1	1	1	1
Type compressor		rotary	rotary	rotary	rotary
Refrigerant		R410A	R410A	R410A	R410A
Refrigerant quantity	kg	0,65	0,80	0,97	1,1
Fan quantity		1	1	1	1
Fan input power	W	70	70	80	80
Fan speed	rpm	950	950	1200	1200
Fan direction		vertical	vertikaal	vertikaal	vertikaal
Noise at 2m	dB(A)	53	54	57	58
Water connection	Inch	1,5	1,5	1,5	1,5
Nominal water flow	m ³ /h	3 – 12	4 – 12	5 – 12	5 – 12
Water pressure drop (max.)	kPa	11	13	15	15
Protection		IP x4			
RCD protection	mA	10	10	10	10
Dimensions	L/W/H(mm)	458/472/530	458/472/530	458/472/750	458/472/750
Unit shipping dimensions	L/W/H(mm)	500/510/580	500/510/580	500/510/800	500/510/800
Net/shipping weight	kg	27/28	29/30	37/39	43/45

* Maximum pool volume when completely insulated, with pool cover, out of the wind and in the sun.

** Measurement conditions: ambient temperature 24°C, water temperature 27°C, relative humidity 70%

2.2 Dimensions



	A	B	C	D
ECO+4	530mm		458mm	472mm
ECO+6	530mm		458mm	472mm
ECO+9		750mm	458mm	472mm
ECO+14		750mm	458mm	472mm

3. Installation and connections

3.1 Remarks

The box contains the heat pump, 2 water connections and this manual. Other parts, including a by-pass must be provided by the user/installer.

Attention:

Please follow these steps when installing the heat pump:

1. All feeding of chemicals to the pool water has to be done **downstream** of the heat pump.
2. Always keep the unit straight up. If the unit has been tilted or put on his side, allow 24h before starting the unit.
3. The unit must always be installed outdoors.

3.2 Heat pump location

The unit will always perform very well, provided the following elements are present:

- 1. Fresh air - 2. Electricity - 3. Swimming pool filter pipes**

The unit may be installed virtually anywhere **outdoors** when minimal distance to other objects is respected.

Attention:

Do not install the heat pump in a closed room to prevent the intake of the cold exhaust air. Do not put it close to garden plants; they could block the intake of fresh air.


Blocking the air intake will cause insufficient operation and will result in lower production of heat.

Please check the drawing on paragraph 3.4 for **minimum** distances.

3.3 How close to the pool?

Install the heat pump as close to the swimming pool as possible to minimize the loss of heat through the piping but stay minimum 2 meters away from the pool. Put it on a solid base. Keep the length of the piping as short as possible to limit heat loss. Insulating the piping will be useful.

3.4 Typical configuration



Remark – This setup is just an example

3.5 Water connections

The piping to and from the heat pump need to have a 50mm outer diameter and need to be glued to water connections that came with the heat pump.

These pipes can be hard PVC or flexible. Always install piping intended for swimming pool use and use the correct glue to put them together.

3.6 Electrical connection

Important – Although the heat pump is electrically isolated from the swimming pool installation, this only prohibits electrical current to or from the swimming pool water. Grounding the heat pump is required to protect you against electrical shock caused by an eventual short circuit inside the unit. Make sure you have a solid grounding.

Always check if the voltage from the network corresponds with the operating voltage of the unit.

The heat pump must only operate together with the filter pump. Both should always be powered together. Therefore, connect them to the same circuit breaker. The heat pump will get damaged when operated without water flow and will void warranty.

Please adhere to the following guidelines for the rest of the electrical installation:

Model	Power supply	Circuit breaker	Running current	Cable section for 15m of cable	Cable section for 50m of cable
ECO+4	220-240V	16A	3,5A	2,5mm ²	2,5mm ²
ECO+6	220-240V	16A	4,6A	2,5mm ²	4mm ²
ECO+9	220-240V	20A	6,5A	2,5mm ²	4mm ²
ECO+14	220-240V	20A	11,7A	2,5mm ²	6mm ²

Values in this table are only guidelines. Check your local regulations.

The heat pump is supplied with a connection cable and can be plugged directly into an outlet. The cable has standard a 10mA RCD.



ATTENTION: test the RCD before use as follows:

1. Plug the RCD into a fixed socket
2. Press the “RESET” button. The indicator should be “ON”.
3. Press the “TEST” button. The indicator should be “OFF”.
4. Press the “RESET” button again to start using the heat pump.

You should always switch off the heat pump immediately when the RCD indicator is turned “OFF”. Be extremely careful when pressing “RESET” after a failure because there might still be a problem.

3.7 Initial startup of the unit

The following steps need to be taken at startup (after verification that all the connections are made according the specifications):

1. Turn on the filter pump. Check for possible water leakage and water flow to and from the swimming pool.
2. Put the power plug into the outlet and switch the heat pump ON. The unit will start after the time delay (see further).
3. Verify after a few minutes that the air exhausted by the heat pump is becoming cooler.
4. Allow the unit and pool pump to run 24 hours per day until desired pool water temperature is reached. When the set temperature is reached, the unit just shuts off. The unit will now automatically restart when the pool temperature drops 1 degree Celsius below set temperature.

Several days will be needed to bring the temperature of the swimming pool water to its required value, depending on the initial water temperature and the ambient temperature. A good pool cover and insulation of the piping can shorten this period considerably.

Time delay – the unit is equipped with a 3-minute built-in delay to protect control circuit components and to eliminate restart cycling and contactor chatter. This time delay will automatically restart the unit approximately 3 minutes after each circuit interruption. Even a brief power interruption will activate this delay and prevent the unit from starting until the 3-minute countdown is completed.

3.8 Condensation

By its operation of heating the swimming pool water, the air taken by the unit is cooled down and water may condense on the fins of the evaporator. If the relative humidity is very high, this could be as much as several liters an hour. Sometimes this condensation water is wrongly considered as swimming pool water.

4. Guidelines

4.1 Water chemistry

Special care should be taken to keep the chemical balance of your swimming pool within following limits:

	Min.	Max.
pH	7,0	7,8
Free chlorine (mg/l)	0,5	1,5
TAC (mg/l)	80	150
TAC (°F)	10	30
Salt (g/l)		8

IMPORTANT: failure to keep the swimming pool water between above limits will void the warranty

NOTE: when the concentration of one or more products mentioned above becomes too high, irrevocable damage to your heat pump may occur. Make sure that you always install water treatment equipment after the heat pump.

When an automatic chemical feeder is installed in the plumbing, it must be installed downstream of the heat pump.

A check valve must be installed between the heat pump and the chemical feeder to prevent back siphoning of chemically saturated water into the heat pump where it will damage the components.

4.2 Winterizing

Caution: failure to winterize could cause damage to the heat pump and will void warranty

Although our ECO+ heat pumps are protected against freezing, it is good practice to drain the complete installation. Perform the following actions to completely drain the heat pump:

1. Turn off the electrical power to the heat pump at the main breaker panel.
2. Shut off the water supply to the heat pump.
3. Disconnect the water inlet and outlet and let the water drain from the heat pump.
4. Re-connect the water inlet and outlet loosely to prevent debris entering the connections.

4.3 Spring startup

If your heat pump has been winterized, perform the following steps when starting the system in the spring:

1. Inspect the system for any debris or structural problems.
2. Connect the water inlet and outlet unions firmly.
3. Turn on the filter pump to supply water to the heat pump.
4. Restore electrical power to the heat pump and switch it ON.

4.4 Control

The ECO+ heat pumps are designed and constructed to provide long performance life when installed and operated properly under normal conditions. Periodic inspections are important to keep your heat pump running safely and efficiently through the years.

The following basic guidelines are suggested for your inspection:

1. Make sure the front of the unit is accessible for future service.
2. Keep the surrounding areas of the heat pump clear of all debris.
3. Keep all plants and shrubs trimmed and away from the heat pump.
4. Keep lawn sprinkler heads from spraying on the heat pump to prevent corrosion and damage. Use a deflector if needed.
5. If the unit is installed under a very sharp roof pitch or under a roof without a gutter, a gutter or diverter should be fitted to prevent excessive water from pouring down onto the unit.
6. Do not use the heat pump if any part has been under water. Immediately call a qualified professional technician to inspect the heat pump and replace any part of the control system, which has been submerged.

The heat pump will produce condensation (water) while in operation. The heat pump base is designed to allow the condensation to exit through the bottom drain port. The condensation will increase as the outdoor air humidity level increases. Visually inspect and clear the bottom drain port of any debris that could clog the port.


The WG heat pump can easily produce 10 to 20 liters of condensation. Stop the unit in case you feel that more water is being generated and wait for one hour to check for leakage inside.

NOTE: A quick way to verify that the water running through the drain is condensation water is to shut off the unit and keep the pool pump running. If the water stops running out of the base pan, it is condensation water. AN EVEN QUICKER WAY - TEST THE DRAIN WATER FOR CHLORINE - if there is no chlorine present, then it's condensation.

Make sure that the air intake and exhaust are free from any restriction. Avoid that the cold exhaust air gets sucked back into the unit.

5. Usage and operation

5.1 The display



The heat pump can be turned on or off with the ON/OFF button.

When OFF the display is showing the following information:

- ◆ The indication 'OFF' at the location of the pool water temperature
- ◆ The temperature wanted for heating
- ◆ Eventual error messages

When ON the display is showing the following information:

- ◆ The temperature wanted for heating
- ◆ The pool water temperature
- ◆ The indication 'Heating' when the unit is heating the water
- ◆ A graphical representation of the water flow: the flow bar (see further)

5.2 Setting of the desired temperature

The desired temperature can directly be set with the arrow keys. The setting will automatically be stored in memory.

A choice can be made between °C and °F as follows:

- Cut electrical power to the unit
- Press both arrow keys at the same time and restore electrical power to the unit, than release the keys.

5.3 The flow bar

The flow bar is a graphical representation of the water volume through the unit. The heat pumps has it best performance when the flow bar is in the green zone. The graph is only valid after at least 30 minutes of operation.

The flow bar also represents the three-minute time delay before the actual start of the unit. The indication "flow" is not visible; the small block at the very right end of the flow bar is flickering and disappears after a while. When they are all gone, the unit will start.

6. Maintenance and inspection

6.1 Maintenance

- Check the water supply to the unit often. Low water flow and air entering into the system should be avoided, as this will diminish the units' performance and reliability. You should clean the pool/spa filter regularly to avoid damage to the unit as a result of the dirty or clogged filter.
- The area around the unit should be dry, clean and well ventilated. Clean the side heating exchanger regularly to maintain good heat exchange and to save energy.
- Check the power supply and cable connection often. Should the unit begin to operate abnormally or do you smell something unusual around the electrical compartment, switch off the heat pump and have it replaced on a timely manner.
- You should discharge the water at the bottom of the heat pump if the unit will not work for an extended period of time. **The heat exchanger in the unit will not be damaged by frost but the remaining water in the piping can become ice.** Check all parts of the unit and the installation carefully before starting.

6.2 Trouble shooting guide

Improper installation will create an electrical hazard, which could result in death or serious injury to pool users, installers, or others due to electrical shock, and may also cause damage to property.

DO NOT attempt any internal adjustments inside the heater.

1. Keep your hands and hair clear of the fan blades to avoid injury.
2. If you are not familiar with the pool filtering system and heater:
 - a. **Do not** attempt to adjust or service without consulting your dealer, professional pool or air conditioning contractor.
 - b. Read the entire installation and users guide before attempting to use, service or adjust the heater or pool filtering system.
 - c. **Do not start the heat pump until 24 hours after installation to avoid damaging the compressor.**

Note: Turn off power to the unit prior to attempt service or repair.

<i>Problem</i>	<i>Cause</i>	<i>Solution</i>
Heat pump not running		
	1. No electricity	1. Switch on the electrical power
	2. Unit not turned on	2. Switch on the heat pump
	3. Wrong temperature setting	3. Adjust the temperature setting
	4. Time delay still activated	4. Wait 3 min for unit to start
	5. Air temperature below 8°C	5. Wait until temperature has risen
	6. Other	6. See further under 'error messages'
Insufficient heating		
	1. Obstacles blocking air flow	1. Remove obstacles
	2. Ice on the evaporator	2. Turn of the unit (air too cold)

6.3 Error messages

The heat pump will show an error message in case of a problem. The following messages can occur:

1. Low air temp

The heat pump will not start when the ambient air temperature is below 8°C and it will show this message.

Solution: the unit will start as soon as the ambient temperature reaches 8°C.

2. Overheat

The heat pump is not capable of transferring all the heat it has generated.

Solution: check the water flow.

3. High airtemp

This is not a malfunctioning. The unit is indicating that the ambient air temperature is high enough to operate without its fan. The fan is being switched off.

4. Low flow

Insufficient water flow. The fan has stopped but the compressor is still running.

Solution: check the water flow.

5. Flow error

There is too little water flowing through the heat pump and the unit is switched off.

Solution: Check/restore the water flow. The heat pump will start after 3 minutes delay when the flow is sufficient again.

Check the following point when verifying the water flow:

- Is the filter pump running?
- Is the filter pump producing enough water flow:
 - Isn't there too much dirt inside the skimmer basket?
 - Isn't there too much dirt inside the pre-filter of the filter pump?
 - Is the sand filter clean enough: has it been backwashed regularly?
- Is the water opening in the pool large enough to allow for the desired flow?

A RESET of the heat pump is generated when the electrical power supply is interrupted.

7. Warranty

LIMITED WARRANTY

Thank you for purchasing our heat pump.

We warrant all parts to be free from manufacturing defects in materials and workmanship for a period of two years from the date of retail purchase.

This warranty is limited to the first retail purchaser, is not transferable, and does not apply to products that have been moved from their original installation sites. The liability of the Manufacturer shall not exceed the repair or replacement of defective parts and does not include any costs for labour to remove and reinstall the defective part, transportation to or from the factory, and any other materials required to make the repair. This warranty does not cover failures or malfunctions resulting from the following:

1. Failure to properly install, operate or maintain the product in accordance with our published "Installation & Instruction Manual" provided with the product.
2. The workmanship of any installer of the product.
3. Not maintaining a proper chemical balance in your pool [**pH level between 7,0 and 7,8. Total Alkalinity (TA) between 80 to 150 ppm. Free Chlorine between 0,5 – 1,5mg/l. Total Dissolved Solids (TDS) less than 1200 ppm. Salt maximum 8g/l**]
4. Abuse, alteration, accident, fire, flood, lightning, rodents, insects, negligence or acts of Gods.
5. Scaling, freezing or other conditions causing inadequate water circulation.
6. Operating the product at water flow rates outside the published minimum and maximum specifications.
7. Use of non-factory authorized parts or accessories in conjunction with the product.
8. Chemical contamination of combustion air or improper use of sanitizing chemicals, such as introducing sanitizing chemicals upstream of the heater and cleaner hose or through the skimmer.
9. Overheating, incorrect wire runs, improper electrical supply, collateral damage caused by failure of O-rings, DE grids or cartridge elements, or damage caused by running the pump with insufficient quantities of water.

LIMITATION OF LIABILITY

This is the only warranty given by Manufacturer. No one is authorized to make any other warranties on our behalf.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY. WE EXPRESSLY DISCLAIM AND EXCLUDE ANY LIABILITY FOR CONSEQUENTIAL, INCIDENTAL, INDIRECT OR PUNITIVE DAMAGES FOR BREACH OF ANY EXPRESSED OR IMPLIED WARRANTY.

This warranty gives you specific legal rights, which may vary, by country.

WARRANTY CLAIMS

For prompt warranty consideration, contact your dealer and provide the following information: proof of purchase, model number, serial number and date of installation. The installer will contact the factory for instructions regarding the claim and to determine the location of the nearest service center.